

Owners Guide

EcoLite™, Rechargeable Receiver and Optional Light Activator

Introduction

Congratulations on your purchase of a Pet Stop EcoLite™, Rechargeable Receiver. For best results, please read this Guide and all accompanying information. If you have any questions, please contact your local Pet stop Dealer.

Precautions

DO NOT use this product for guard dogs or vicious animals. If you believe your dog may pose a threat to others, **DO NOT USE THIS PRODUCT**

DO NOT use this product as sold barrier. The product is meant to train pets to remain within an established boundary. It will not work without proper training.

DO NOT permit children to use this product.

Additionally, the product will not work unless you:

- Adjust the collar snug enough for the probes to make contact with your pet's skin, but not so tight that it will cause injury.
 - Recharge the battery whenever you see the red blinking light or monthly, whichever is sooner.
 - Train your pet properly.
-  **To avoid neck irritation, always remove the receiver collar from your pet at the end of the day when your pet is inside. Check your pet's neck frequently for any irritation. If irritation occurs, discontinue using the product until the irritation clears up.**

Product Description

The EcoLite is a small and rechargeable receiver. It is molded in a translucent Lexan plastic, known to be a tough and durable plastic.

The translucent nature of the case allows you to see various lights that are incorporated within the receiver itself. These lights include:

- A blinking red light, to alert you that the battery requires charging.
- A solid green light that lets you know the unit is charging
- A blinking white light, which can be activated with the optional White Light Activator. The White Light is used to help dog owners see their dog in low light conditions or at night.

The EcoLite incorporates additional security features to guard against false activation. Also, the signal detection scheme is as fast as or faster than any product currently on the market. The EcoLite receiver incorporates three antennas to be Omni-directional and also a safety shut-off should there is ever a malfunction.

Charging the Receiver

Included with the EcoLite is a plug-in wall charger, a small Allen wrench and a spare screw cap. The charger is used to charge the internal rechargeable battery of the EcoLite receiver. The Allen wrench is used to remove the protective cap to expose the charging port. The spare cap is provided in case you lose the protective charging cap.

To charge the EcoLite, simply use the Allen wrench to remove the protective cap covering the charging port. Plug the charger into any service outlet and the charging port into the EcoLite receiver. When inserting the charging port, push gently until you feel a 'click'. When the EcoLite is charging, a solid green light can be seen through the EcoLite case. When fully charged, the solid green light will turn off.

The Optional Light Activator

Position the optional White light Activator to within about 6 to 16 inches of the EcoLite Receiver and press the button on the Activator. The White Light should begin blinking about every 6 seconds. To deactivate the light, again position optional White Light Activator to within about 6 to 16 inches of the EcoLite receiver and press the button on the Activator. (The EcoLite will blink three times before shutting off). We recommend using the White Light Feature for limited periods to conserve the battery.

To change the battery, remove the three screws on the back of the Activator and replace the battery using a 2450 lithium cell.